

## NOTE:

- 1. APPLY ROOF SEALANT TO BOTTOM OF PENETRATION FLANGE AND DIRECT TO ROOF DECK.
- 2. FASTENERS AS PER STRUCTURAL CALCULATIONS..

## **PV MOUNT DETAIL "G" - LOW SLOPE**

SCALE

ISSUEJ**DATN**EJMBER

N.T.S.

release date 09-13-2022